





MIRRORS

#P112 - Hand Mirrors

Want to let someone know how special they are? What better way to enchant her than with one of these beautifully crafted hand mirrors! Mirrors range from 12" - 15" long.




**B, D
or F**
Work
piece

1 Cut mirror opening and interior design only. Do not cut the outer shape.

2 Glue and clamp Back work piece to Frame work piece. Cut outer shape of mirror.

Beveled mirror



Frame/Back Assembly



3 Silicone mirror into place. Glue Overlay into place if required.


#P112 - Hand Mirrors


Description	Item	Qty	Size
Frame	A	1	1/8" - 1/4"T x 7 1/2"W x 12 1/4"L
Back	B	1	1/4" - 3/8T x 7 1/2"W x 12 1/4"L
Frame	C	1	1/8" - 1/4"T x 7 3/8"W x 15"L
Back	D	1	1/4" - 3/8T x 7 3/8"W x 15"L
Frame	E	1	1/8" - 1/4"T x 7 1/2"W x 13 3/8"L
Back	F	1	1/4" - 3/8T x 7 1/2"W x 13 3/8"L

#P112 - Assembly Instructions

1. Select your material from a variety of hardwoods or solid core plywood.
2. Measure each pattern piece and cut the work pieces to size accordingly. Sand as necessary.
3. Make all pattern pieces by adhering the paper patterns to the work pieces with a repositionable spray adhesive.
4. Drill the starter holes and cut the opening for the mirror in the Frame. Next cut the interior design ONLY in the Frame - DO NOT cut the outer shape at this time.
5. Before proceeding any further, check to make sure the mirror fits properly within the Frame.
6. Next, lightly apply a thin layer of glue to the backside of the Frame. Be careful to only apply it to the flat surfaces and not into the fretwork. A painting or cosmetic sponge works well for this step. Next, align the Frame onto the Back and clamp into place while the glue dries. Note - clamping the work piece between 2 slightly larger boards will help to apply even pressure.
7. Once the glue has dried, remove the clamps and cut along the solid outside line.
8. Remove the paper pattern and sand if necessary. Finish as desired and secure the beveled edge mirror in place with a small amount of silicone. Note - if you prefer, the individual pieces can be finished prior to gluing them together.








Frame (C)/Back (D)

Front Stock: 1/8" - 1/4"

Back Stock: 1/4" - 3/8"

Top pattern piece.

Note: Factory made beveled mirrors are not 100% consistent in size and shape. Therefore, we recommend that you position the mirror in place on the pattern and trace around it with a red pen. Then cut on this solid line for the mirror to fit properly.



#P112